

Color Guide for SpectroEye Upgrade Procedure

To upgrade the SpectroEye with a color guide (e.g. Pantone Formula Guide), we recommend upgrading at the same time the latest SpectroEye firmware version. For the upgrade, the Download Utility Software version 1.50 or higher is required.

Please proceed as follows for the color guide upgrade:

1. Install Download Utility version 1.50 or higher (it is very important to use at least version 1.50, as the previous versions may crash).
2. Check for the latest firmware version in the SpectroEye product section on our website www.xrite.com.
Check the firmware version of the SpectroEye. Therefore select in the SpectroEye menu "Main Menu > Settings > General > Instrument type".
If the version in the SpectroEye is not up to date, upgrade the SpectroEye with the latest firmware version (see instructions below).
3. Download the desired color guide guides (see instructions below).

Download SpectroEye Firmware

If the Download Utility is installed and the SpectroEye is connected to the PC, please proceed as follows:

1. Download the latest firmware version from the SpectroEye product section on our website www.xrite.com.
2. Copy the unzipped firmware to the "data" directory of the Download Utility.
3. Start the Download Utility.
4. Select the "Software" button of the Download Utility to download the new firmware.

For more information, please refer to the user manual of the Download Utility.

Download Color Guides

If the Download Utility version 1.50 or higher is installed, the SpectroEye is connected to the PC and the SpectroEye is loaded with the latest firmware version, please proceed as follows:

1. Download the desired color guides from the SpectroEye product section on our website www.xrite.com.
2. Copy the unzipped color guides to the "data" directory of the Download Utility.
3. Select the "Data Files" button of the Download Utility to start downloading the color guide.
4. Select "Color Guide File" in the appearing message box and thereafter select the desired color guide.
5. Repeat step 2 to 4 for all desired color guides.

By upgrading the SpectroEye with the color guides, the memory disk of the SpectroEye could get full. In this case, a message appears where you have to confirm that the memory will be formatted. All color guides and languages in the SpectroEye will be lost. Thereafter all required color guides and languages have to be downloaded to the SpectroEye again. Please refer to the X-Rite website for the data of the different color guides and languages.

Remark: After downloading the color guides, all available color guides and languages may be stored in the SpectroEye together.

For more information, please refer to the user manual of the Download Utility.